

Open Source Audio Platform: Ultrasound Dosimeter

Jennifer Cooper, Jordan Schleif, Adaleena Mookerjee, Tyler Flynn, O.H. Ott-Pietrak,
Shane Lani

Dec 2, 2021

Motivation

- Recent news articles suggest illness in diplomats caused by ultrasound
 - News media descriptions of the issue are muddled and difficult to assess



Washington Post, Oct 10, 2021

Motivation

- Loud noise above 15kHz can cause annoyance, headaches, etc, especially in younger listeners
- Others in the same space may not hear it
 - Auditory band differs among individuals
- Sounds up to ~20 kHz can be observed in smartphone apps, but not far above that

Table 1. Examples of incidental or deliberate exposures from commercial devices


Incidental or Deliberate Exposure?	Commercial Source	Frequency	SPL Levels at the Possible Position of the Human Ear	Reference for Measurement
Deliberate	Pest deterrents: Used to deter birds, rodents, and insects away from locations (barns, homes, and shops)	20-kHz TOB	130 dB at 1.6 m 90 dB at 14 m	Ueda et al., 2014a,b
			92 dB at 1.7 m	Dolder et al., 2018
Deliberate	Teen deterrent: Exploits high-frequency sensitivity of teenagers and children to deter them from shops as age-discriminatory deterrent to make the shop more welcoming to older customers who are assumed to have greater purchasing power and be less likely to steal.	12.5-kHz TOB	72 dB at 1.5 m	Conein, 2006
		16-kHz TOB	92 dB at 1.5 m	
		20-kHz TOB	80 dB at 1.5 m	
Incidental	Public-Address-Voice-Alarm: Speakers, usually set in ceilings or high on walls in public places to alert people, e.g., to evacuate in case of bomb threat or fire; by EU law must be monitored to ensure they are functioning. Many types produce a ~20-kHz tone as a by-product of this monitoring.	~20 kHz	76 dB	Fletcher et al., 2018c
			65 dB	Paxton et al., 2018
			43-82 dB	Mapp, 2018
Incidental	Acoustic spotlights: Two high-intensity ultrasonic beams overlap, and the nonlinear difference frequency produces a low-power audible signal so that listeners to recordings who share a space do not bother one another (for museums, exhibitions, and homes). It is not known whether anecdotal reports of adverse effects, if confirmed, would be due to the fundamental, a subharmonic produced by the source of a nonlinearity in propagation, or when the ear is driven by the signals.	~20 kHz	53 dB at 3.5 m	Dolder et al., 2019 Sapozhnikov et al., 2019
		~40 kHz	118 dB at 3.5 m	
Incidental	Haptic feedback: ultrasonic beams (e.g., above a computer keyboard) produce modulated radiation pressure that gives the sensation resembling "soap bubbles bursting on the skin."	~40 kHz	125 dB at 60 cm	Battista, 2019
			155 dB at 20 cm	Lieber et al., 2019

SPL, sound pressure level; TOB, third-octave band; EU, European Union. See Leighton, 2016a, for details of devices. Reproduced from Leighton et al., 2020.

Project Overview


- Create quick, easy, open source way to screen rooms for extraneous ultrasound across entire band
 - Higher frequencies than available on smartphone apps
 - User can listen to frequency shifted audio to help identify sources that are out of the ordinary
 - Would need to follow up with better (calibrated) tools if you found anything
- Other questions we can answer with this work
 - Is my cat disturbed by high frequency sound coming from the TV? Why does he run away?
 - Can we hear bats in the neighborhood (work in progress)
 - Frequency shifted sounds are cool – scare the kids on Halloween!

Ultrasonic Ranger, 40 kHz Active Pings



Approach

- Use Arduino based open source Tympan platform
 - No circuits to build, just coding
 - Code can be shared for others to build on
- Team includes acousticians and experienced C++ programmer
- Compute 1/3 octave band levels
- Compare high frequencies to lower frequencies
- Alert if energy only at high frequency
- Allow user to listen for themselves



<https://github.com/Tympan/Docs/wiki/Getting-Started-with-Tympan>

Compute (Uncalibrated) Octave Band Levels Below 20 kHz And 1/3 Octave Band Levels Above 20 kHz

Example Serial Monitor Output

```
[offline] (Teensy)
Ultrasound detected: 18.72 is greater than -8.59
SPL Level: 47.00, 18.51, 14.35, 3.83, 1.34, -5.65, -11.48, -15.46, -12.34, -8.43, -7.10, -7.50, 25.06, -6.48,
Ultrasound detected: 25.06 is greater than -7.10
SPL Level: 46.84, 16.91, 18.07, 9.74, 18.37, 14.75, 4.02, 3.28, -0.23, 4.15, -2.92, -6.28, 24.76, -4.25,
Ultrasound detected: 24.76 is greater than -2.92
SPL Level: 46.19, 12.60, 12.23, 4.76, 11.30, 3.17, -7.90, -12.15, -11.80, -7.77, -5.40, -7.80, 25.76, -7.43,
Ultrasound detected: 25.76 is greater than -5.40
SPL Level: 47.36, 26.36, 15.90, 10.09, 17.51, 19.57, 13.33, 5.62, 3.93, 7.58, 2.77, -2.27, 14.57, -11.23,
Ultrasound detected: 14.57 is greater than 2.77
SPL Level: 46.34, 23.07, 9.73, 5.33, -0.37, -2.90, -12.22, -16.14, -14.90, -8.59, -2.37, -5.05, 7.16, -16.55,
Ultrasound detected: 7.16 is greater than -2.37
SPL Level: 46.51, 15.67, 8.41, 3.23, -0.87, -6.28, -12.23, -15.46, -14.37, -8.20, -2.28, -10.81, -10.39, -22.20,
SPL Level: 42.91, 29.41, 24.66, 20.17, 31.86, 28.85, 21.40, 12.56, 4.49, 8.48, 5.50, -1.65, -5.03, -12.95,
SPL Level: 45.42, 14.05, 8.87, 7.01, 3.41, 5.91, -0.03, -8.53, -11.22, -2.35, -4.20, -11.95, -14.30, -18.19,
SPL Level: 47.23, 16.33, 11.08, -0.99, -2.44, -6.19, -14.21, -15.24, -14.32, -8.60, -5.53, -13.47, -5.55, -21.38,
SPL Level: 46.33, 18.81, 15.54, 3.67, 2.13, -3.92, -11.09, -14.30, -13.70, -8.78, -6.94, -7.73, 26.46, -1.80,
Ultrasound detected: 26.46 is greater than -6.94
SPL Level: 47.36, 19.80, 10.63, 3.65, 1.17, -8.59, -13.06, -15.50, -15.09, -8.32, -6.76, -14.19, -14.50, -22.06,
SPL Level: 47.07, 23.55, 17.36, 3.59, 1.97, -11.96, -14.18, -13.98, -7.96, -6.15, -13.95, -0.03, -20.78,
Ultrasound detected: -0.03 is greater than -6.15
SPL Level: 46.02, 22.59, 27.00, 25.51, 22.89, 18.45, 8.24, 1.18, -6.18, -1.61, -3.15, 10.55, 48.47, 21.68,
Ultrasound detected: 48.47 is greater than -3.15
SPL Level: 46.29, 25.91, 16.59, 17.05, 14.14, 15.60, 7.64, -6.77, -10.96, -4.18, -5.81, -14.84, -12.87, -19.72,
SPL Level: 47.36, 20.01, 9.68, 1.32, 0.53, -3.61, -10.63, -11.30, -13.32, -7.22, -7.01, -14.03, 3.43, -20.89,
Ultrasound detected: 3.43 is greater than -7.01
SPL Level: 46.82, 14.91, 8.70, 7.01, 0.28, -6.58, -11.32, -12.19, -8.62, 1.07, -3.88, -13.03, -14.69, -20.97,
SPL Level: 46.67, 14.60, 10.55, -0.53, -3.09, -8.06, -13.69, -15.05, -13.92, -8.91, -7.05, -14.00, -16.05, -22.81,
SPL Level: 46.76, 15.27, 12.21, 2.59, -2.05, -7.02, -13.74, -15.18, -14.16, -8.68, -6.24, -14.69, -16.11, -21.95,
SPL Level: 47.08, 20.65, 11.42, 6.63, -1.74, -7.42, -12.99, -15.46, -14.20, -8.65, -6.57, -14.22, -15.67, -22.22,
SPL Level: 47.07, 17.97, 6.80, 7.85, -0.74, -6.47, -14.72, -16.47, -14.51, -7.94, -7.75, -14.36, -15.84, -23.42,
SPL Level: 46.85, 17.09, 12.15, 8.67, -3.07, -6.55, -12.47, -15.90, -15.04, -9.66, -6.88, -14.34, -15.25, -22.38,
SPL Level: 47.54, 18.31, 9.31, 3.20, -1.51, -7.72, -14.91, -15.17, -13.85, -9.06, -7.04, -13.65, -15.85, -22.71,
SPL Level: 47.11, 18.30, 11.31, 2.67, -0.88, -5.76, -9.92, -12.98, -13.07, -8.57, -6.15, -14.23, -15.27, -21.04,
SPL Level: 46.98, 13.26, 13.48, 7.50, -3.40, -9.32, -15.09, -13.93, -8.28, -6.95, -14.72, -14.51, -21.85,
SPL Level: 46.77, 12.93, 9.85, 23.13, 17.61, 11.49, 3.54, -6.01, -2.05, 3.68, -3.65, -13.64, -15.34, -20.45,
Command Received: setting frequency downshift to 25kHz
SerialManagerBase: sending: STATE=BTN:ShiftA:0
```


Example Bluetooth App Plotter

1 Octave
Frequency
bands

Serial Plotter



Start Plot

Stop Plot





Play Back Through Headphone Jack

- Ultrasound shifted down to audible in left channel and audio with low pass filter in the right channel
- Record frequency shifted and raw audio to SD card (one on each channel in the .wav file) when user selects





Alert If Irregular Ultrasonic Energy Is Observed

- Alert = Flash the light and report to serial monitor
- Threshold: level in any of the ultrasound 1/3 octave bands exceeds the level in the band just below 20kHz
- Levels are averaged over the band and corrected back to spectral level units (dB/Hz)
- Still uncalibrated, but the relative levels should be accurate




Bluetooth Controls

Tympan App on smartphone allows control over frequency shift (10, 20, 25 kHz) and SD card recording



Lessons Learned



- The Tympan has a configurable sample rate, enabled by sigma-delta ADC
 - But at sample rates $> \sim 110\text{kHz}$, it can't really keep up, and spectral content is splattered



Lessons Learned

- Using ultrasonic ranger for Arduino in initial tests, we heard clicks in audio from the Tympan but not with our ears.
 - Adjusting the input gain to avoid saturation/clipping for an ultrasound source you can hear
 - It was evident when looking at the recorded waveform

Ranger recorded with 25 dB input gain



*Note difference in yaxis limits

Next Steps

- Improve the threshold for questionable ultrasound levels
 - Ideally, would need access to something that looks like “ultrasonic weapons” to test against
- Calibrate the built-in mic at ultrasound frequencies or use an external calibrated mic
 - Resonance peak typical in 20-40 kHz band for mics intended for audio
 - Need to adjust the threshold for alerting afterward
- Improve the responsiveness
 - Processing in blocks means that if a transient sound does not align with the block, it may not register fully
 - energy will be split between blocks
 - Arduino works in a continuous loop, only acting on the blocks periodically. Again some transients will be missed

Fun With Frequency Shifting




Mild Mannered Scientist
Becomes Feared Monster



Safety Pins Sound Awesome



Officemate Enhancement





JOHNS HOPKINS

APPLIED PHYSICS LABORATORY